



west virginia

Department of Transportation



PST1

PRH1

LOADING ZONE KEEP CLEAR OF OPERATOR

T1

C1

G1

T2

DO NOT ENTER

Crane MAINT.
Area do not enter

NO
TRUCK
TRAFFIC

General Information

- Channel 17 for lift operator
- C1 bare chassis lot
- T1/T2 for in gated units
- G1 for out gate units
- Billing questions call 800-497-2919

OFFICE